

Foodservice Equipment • Material Handling, Healthcare & Cleanroom Equipment • Retail Display

Exchange Carts

ECDT, ECET, ECD7 and ECE7 Series



patented
QuadTruss®
design
(patent #5,390,803)

Item #:	_____
Model #:	_____
Project #:	_____
SIS #:	_____

Optional Accessories	Model #	Qty.
Dividers		
Tote boxes		
Tote slides		
Additional shelf markers		
Cart covers		



ECET Series exchange cart

- **Versatile** - Eagle offers exchange carts with various shelving configurations, caster styles, accessory packages, and in various sizes to meet all requirements for supply exchange in any healthcare environment.
- **Adaptable** - exchange carts can be readily altered to meet changes in use for supply, volume and packaging requirements; by adding or removing accessories a multitude of combinations can be made to customize an exchange cart for a specific use.
- **Assembly** - numerically calibrated grooved posts, tapered high-temperature-resistant plastic split sleeves and shelf collars combine to make shelving assembly a simple two-step exercise: 1) Snap the split sleeves onto the posts at the location of your choice; 2) Slide the shelf collars over the split sleeves. A positive lock between the shelf and the split sleeves is created without the use of any tools, becoming stronger as additional weight is added to the shelving.
- **Open-wire construction** - promotes higher visibility by allowing light to pass through the shelves, permits greater air circulation which helps reduce dust and contamination build up, and increases the effectiveness of fire-suppression systems.
- **Posts** - posts are numbered on vertical one-inch increments to help ensure fast and level assembly; shelving can be adjusted up and down every inch for optimum cart configuration.
- **Finish** - all components are chrome plated.

System Benefits

- **More-accurate inventory control** - inventory of exchange carts can be strictly monitored allowing for quick and efficient control of usage.
- **Improved handling and flexibility** - carts are handled only once between stocking and patient distribution, thus eliminating par level inventory taking and retrieval of needed supplies; changes in patient requirements can be instantly responded to with adjustments in type and quantity of supplies.

Spec sheets available for viewing, printing or downloading from our online literature library at www.eaglegrp.com

For custom configuration or fabrication needs, contact our **SpecFAB Division**.
Phone: (302) 653-3000. FAX: (302) 653-3091.
E-mail: specfab@eaglegrp.com

Exchange Carts

ECDT Series



shelf width x length		height	weight		tote boxes		tote boxes		shelves	model #
in.	mm	in. mm	lbs.	kg	3" (76mm)	6" (152mm)	9" (229mm)			
21" x 60"	533 x 1524	70" 1778	231	104.7	1	4	1	5-wire	ECDT2160C	
21" x 60"	533 x 1524	70" 1778	241	109.3	1	4	1	4-wire, 1-solid	ECDTS2160C	
24" x 60"	610 x 1524	70" 1778	246	111.6	1	4	1	5-wire	ECDT2460C	
24" x 60"	610 x 1524	70" 1778	256	116.1	1	4	1	4-wire, 1-solid	ECDTS2460C	

- Four chrome-plated wire shelves.
- Choice of chrome-plated wire solid or stainless steel fifth shelf.
- Chrome-plated 63" (1600mm) posts.
- Chrome dolly frame with wraparound bumper.
- 6" (152mm) polyurethane casters – two with brake.
- Three slide assemblies.
- Six tote boxes with box dividers.
- Three shelf dividers.
- Six plastic shelf markers.

ECET Series



shelf width x length		height	weight		tote boxes		tote boxes		shelves	model #
in.	mm	in. mm	lbs.	kg	3" (76mm)	6" (152mm)	9" (229mm)			
21" x 60"	533 x 1524	72" 1829	250	113.4	1	4	1	5-wire	ECET2160C	
21" x 60"	533 x 1524	72" 1829	260	117.9	1	4	1	4-wire, 1-solid	ECETS2160C	
24" x 60"	610 x 1524	72" 1829	262	118.8	1	4	1	5-wire	ECET2460C	
24" x 60"	610 x 1524	72" 1829	272	123.4	1	4	1	4-wire, 1-solid	ECETS2460C	

- Four chrome-plated wire shelves.
- Choice of chrome-plated wire or solid stainless steel fifth shelf.
- Chrome-plated 63" (1600mm) posts.
- Side and back enclosure panels.
- Chrome dolly frame with wraparound bumper.
- 6" (152mm) polyurethane casters – two with brake.
- Three slide assemblies.
- Six tote boxes with box dividers.
- 12 plastic shelf markers.

ECD7/ECE7 Series



shelf width x length		height	weight		tote boxes		shelves	other	model #
in.	mm	in. mm	lbs.	kg	3" (76mm)	6" (152mm)			
24" x 60"	610 x 1524	72" 1829	226	102.5	2	5	5-wire	shelf dividers	ECD72460C
24" x 60"	610 x 1524	72" 1829	236	107.0	2	5	4-wire, 1-solid	shelf dividers	ECD7S2460C
24" x 60"	610 x 1524	72" 1829	250	113.4	2	5	5-wire	enclosure panels	ECE72460C
24" x 60"	610 x 1524	72" 1829	260	117.9	2	5	4-wire, 1-solid	enclosure panels	ECE7S2460C

- Four chrome-plated wire shelves.
- Choice of chrome-plated or solid stainless steel fifth shelf.
- Chrome-plated 63" (1600mm) posts.
- Models #ECD72460C and ECD7S2460C come with three shelf dividers.
- Models #ECE72460C and ECE7S2460C come with side and back enclosure panels.
- Chrome dolly frame with wraparound bumper.
- 8" (203mm) polyurethane casters – two with brake.
- Three slide assemblies.
- Seven tote boxes with snap on card holders and box dividers.
- 12 plastic shelf markers.